

Our durable, waterproof stair treads make it easy to upgrade your stairway in style and with minimal upkeep down the road. Treads are made to match corresponding CALI Vinyl flooring planks for a sleek, seamless installation.

Product Features

- 100% waterproof and easy to clean
- Shielded by a protective scratch-resistant wear layer
- Pre-attached nosing for clean look and simple front installation
- Works with closed stairs or stairs with an exposed side view
- Easy to install for DIYers and professionals alike
- End cap included which can be cut to size on the right or left side



STAIR TREAD

48" long x 12" wide x 8.5mm thick
1 tread per carton

STAIR RISER

48" long x 7.5" wide x 12.7mm thick
1 riser per carton



How to Install

Helpful Installation Tools

- Personal Protective Gear (Gloves, Safety Glasses, Dust Mask, etc.)
- Measuring Tape
- Pliers
- Hammer
- Vacuum
- 5-in-1 Tool or Scraper
- Heavy-Duty Construction Adhesive
- Caulking Gun
- Sliding Miter Saw with Carbide Tipped Blade
- Table Saw with Carbide Tipped Blade
- T-Bevel or Angle Gauge
- 100-Grit Sandpaper
- Denatured Alcohol
- Matching Wood Filler

Pre-Installation Steps

Before installing, ensure your steps are clean, stable, and free of debris. Remove any old carpet, padding, and staples, and make sure there are no protruding nail heads that might get in the way. If your stairs have loose or squeaky spots, give them a quick fix before moving forward.

Measuring & Cutting

Start by measuring the width and depth of each step. Use a T-Bevel or an Angle Gauge to get an accurate measurement. It is possible that each step will vary slightly in size. Using a sliding miter saw, trim the stair tread to the proper width, and cut to the correct depth with a table saw.

Installation

Start installing at the bottom of the staircase and work your way up. For each step, install the riser first and then the tread. Start by applying a ¼" bead of construction adhesive to the back of the riser – around its perimeter and in a serpentine pattern across its middle. Fit into place and secure with matching caulking if needed.

We recommend lightly sanding the bottom of the stair tread and then wiping it clean with denatured alcohol in order to achieve a secure grip. Then, apply adhesive to the bottom of the tread in the same way you applied it to the riser. Fit it snugly in place and move on to the next step, repeating this process until you reach the top of the staircase.

Expert Tip: Note that if your staircase has pre-existing spindles, you'll need to remove them before installing your new treads, and then re-install them once you're done. Cutting around spindles isn't recommended.

Finishing Up

After installation, fill any gaps around the treads and risers with caulk for a clean, finished look. For open steps, an end cap can be used to provide a more finished look. Otherwise, a small trim piece may be used to conceal the riser's edge. Miter the end cap to fit, and secure it with nails or glue.